

E-Z CUT INC.

“EC-1” CARPET CUTTING MACHINE



OPERATING MANUAL

Version 3.1

CONTENTS

INTRODUCTION.....	3
MACHINE'S ARRIVAL AND PREPARATION	3
MAIN OPERATING PROCEDURES.....	4
PROGRAMMING THE COUNTER.....	5
REVERSE ROLLING PROCEDURES	11
VINYL PROCEDURES	13
“EXTRA SUPPORT PIN” ON ROLL-UP SIDE CRADLE.....	13
IMPORTANT SAFETY AND MAINTENANCE TIPS.....	14
ROUTINE MAINTENANCE SCHEDULE	15
RECORD OF MAINTENANCE	16
GEARBOX OIL REPLACEMENT	17
TROUBLESHOOTING THE COUNTER.....	18
TROUBLE SHOOTING MEASURING ACCURACY PROBLEMS.....	19
ADJUSTING THE TOP COUNTER PRESSURE WHEEL.....	21
BLADEHOLDER INSTRUCTIONS	22
EC-1 PARTS LIST	23
WARRANTY.....	Error! Bookmark not defined.

INTRODUCTION

- Read these instructions carefully and thoroughly so as to ensure that you are familiar with the machine's features, general operating functions and the safety and maintenance requirements.
- Only authorized personnel who are familiar with the machine and its operation should use it. Never allow children near the machine.
- Keep the area of operation clear of any and all potential hazards.
- The following procedures are intended to acquaint you with the safe and efficient operation of your E-Z CUT Cutting Machine. Try to abide by the rule: "If at first you don't succeed, try again". This machine is a proven tool for improving your warehouse and cutting efficiency. Take your time, be patient, and enjoy the benefits of this machine for many years to come.
- If assistance is required or if any of the following procedures are unclear, please do not hesitate to contact an E-Z CUT representative directly at **1-800-661-5156**.

MACHINE'S ARRIVAL AND PREPARATION

- Once all 4 wheels are on the floor, you can move the machine to the desired position for operation on your warehouse floor. The machine should be located in a dry location and operated at a comfortable temperature. Extreme **heat and humidity or cold temperatures** could lead to electronic problems or even damage to the electronics on your machine. See chart below for approximate temperature (**including humidity**) ranges.

COLD	35°F Or Lower	2°C Or Lower	May Cause Damage To Electronics
COOL	45°F Or Lower	7°C Or Lower	May Cause Problems With Electronics
OPTIMAL	70°F	21°C	Optimal Operating Temperature
WARM	95°F Or Higher	35°C Or Higher	May Cause Problems With Electronics
HOT	110°F Or Higher	43°C Or Higher	May Cause Damage To Electronics

- When you have located the machine to your desired position, use the Caster Wheel Locks so as to minimize any movement during actual operation.
- Hook-up the machine's 4 Wire Power Cord into the following power source (Hardwired or Plug).

115 / 230V (Single Phase) / 60 Hz / 20 Amp



IMPORTANT WIRING NOTE: THE WHITE WIRE ON THE MACHINE'S POWER CORD MUST BE CONNECTED TO THE NEUTRAL ON YOUR POWER SUPPLY.

➤ Test the activation of the rollers by turning both Roller Switches to FWD and then press and hold the Jog Button. The rollers should now turn and then stop when you remove your finger from the button. Next, with the Roller Switches still in FWD, step on the Foot Cable section located along the front of the machine. Again, the rollers should turn and then stop when you remove your foot from the cable. Test the Foot Cable along both sides of the machine.



➤ Check that the Cutting Bar is working by pushing & holding the Cutter Switch to FWD. Since it is a Two-Way Cutter, you can make your next cut by pushing & holding the Cutter Switch to REV.

IMPORTANT NOTES:

- **EXCESSIVE AND PROLONGED “TAPPING” OF THE JOG BUTTON AND/OR THE FOOT CABLE WILL CAUSE PREMATURE MOTOR FAILURE.**
- **The Cutting Bar only takes about 10 seconds to travel the length of the Cutting Track. Should you ever have to stop the Cutter, just release the Cutter Switch and the Cutter will stop. Use extreme caution, care and common sense when operating this Cutter!**

MAIN OPERATING PROCEDURES

LOADING THE ROLL OF CARPET

Place the roll on the Left Hand Side Cradle and ensure that the "Feed Edge" is coming from the Bottom towards the Counter with the "Pile" facing Up. Whenever possible load rolls from the **rear** of the machine to avoid damaging the control panel. **Never measure with the “Pile” facing Down as this will result in inaccurate readings.** For best results turn the Left Hand Side Rollers in Reverse (REV), press the Foot Cable or Jog Button, and allow the roll to rotate a few turns until it tightens



PREPARING TO MEASURE

Lift the Counter Weight Arm to the Up position. Advance the carpet towards the Right Hand Side by switching both the Left and Right Side Rollers to Forward (FWD), and depressing the Foot Cable or Jog Button. You may find it easier to get the roll started by using the Jog Button instead of the Foot Cable. Stop the advancement of the carpet at the Cutting Track and lower the Counter Weight Arm down onto the carpet.



PROGRAMMING THE COUNTER

MAIN SCREEN

Display reads:

C 0.00
P2 10.00











- Ensure you are in the "C / P2" Main Screen as shown in the photo above.
- The Top Row (C) will indicate the actual length of the flooring that will be measured while the Bottom Row (P2) is where you can program the desired or pre-set length you wish to measure.

PRE-SET SCREEN

Display reads:

PROCESS
P2 10.00




1. Press the  (PRS) button to get into the "PROCESS" Pre-Set Screen.
2. Press the  (SEL>) button and you will notice that the first digit position on the Bottom Row (P2) will begin to flash. Press the  (UP) or  (DOWN) buttons to change the value of the flashing digit. Press the  (<ESC) or  (SEL>) buttons to move to the next digit.
3. When you have reached the desired values at each position, press the  (ENT) button and this will lock in your Pre-Set amount. If you have made an error or wish to make any changes, just start the process over again.
4. Press the  (<ESC) button and this will return you to the "C / P2" Main Screen. You will notice that the Bottom Row (P2) will have the Pre-Set amount that you have programmed into it.

EXAMPLE

Display reads:


C 0.00
P2 18.06



- For Example if you need to make an **18' 6"** cut, simply program the Pre-Set length in the **"PROCESS"** Pre-Set Screen to read **"18.06"**.
- Advance or reverse the carpet so it is lined up with the Cutting Track. Once aligned with the Cutting Track, press the  (**F2/RST**) button to clear the Top Row (**C**) to "0.00".

IMPORTANT NOTE: NEVER LEAVE THE P2 SET TO "0.00". IF YOU DO NOT WANT TO PRESET YOUR CUTS PROGRAM A NUMBER THAT WILL BE LARGER THEN ANY CARPET THAT YOU WILL BE MEASURING INTO THE P2 SCREEN.

ADVANCING THE CARPET TO THE CUTTING TRACK

- Advance or reverse the carpet so it is lined up with the Cutting Track. Once aligned with the Cutting Track, press the  (**F2/RST**) button to clear the Top Row (**C**) to "0.00".

STARTING THE ROLL UP PROCESS

With both Rollers in the FWD position and the Counter Weight Arm in the Down position, advance the carpet by depressing the Foot Cable or Jog Button as well as assisting the carpet by hand until it is into the Right Hand Side Cradle and stop it's progress when it advances just past the middle of the Right Hand Side Cradle (approx. 4 to 6 inches). Although it is not necessary, should you require a core, it can be placed on top of the carpet in the Right Hand Side Cradle at this time.

ROLLING UP THE CARPET

- With both rollers in FWD, raise the Right Hand Side Cradle up and curl itself over the portion of the carpet sitting in the cradle.
- Step on the Foot Cable or press the Jog Button to advance the carpet further into the Right Hand Side Cradle. You will notice that the carpet will curl over and start to re-roll itself. At the same time, apply a small amount of pressure by holding the Cradle Handle in place over the carpet.
- Once you have rolled up approximately 3 to 5 feet (3 to 5 turns), you can gently return the Right Hand Side Cradle back to its Normal position.

NOTES:

- Once you practice more and become more familiar with the machine, these steps will become more integrated and much easier to perform.
- If the carpet does not seem to want to roll up in the Right Hand Side Cradle immediately, just stop the process, reverse the carpet back a little and start over. You may have to jog/bounce the Right Hand Side Cradle Handle a little bit during the roll-up to assist in getting the carpet started. Also, if you experience "buckling" of the carpet during this process, just turn the Left Hand Side Rollers to OFF for a split-second and then back to FWD once the buckling is removed. **Be Patient It Will Work!**
- Should you prefer a more loose roll-up of your carpet, just pull the Right Hand Side Cradle Handle back earlier than after 3 to 5 turns or don't even engage the Right Hand Side Cradle at the start. **Experiment to see what works best for you.**



IMPORTANT NOTE: IF YOU CONTINUE THE ROLL-UP PROCEDURE BY PRESSING THE JOG BUTTON INSTEAD OF THE FOOT CABLE, THE MACHINE WILL NOT STOP AUTOMATICALLY AT YOUR PRE-SET LENGTH. BE SURE TO USE THE FOOT CABLE AFTER YOU HAVE STARTED THE CARPET SO THIS FUNCTION CAN PERFORM PROPERLY.

ROLLING UP THE CARPET STRAIGHT

➤ As long as your floor and machine are level and the main roll on the Left Hand Side Cradle is rolled up relatively straight, then the carpet will roll-up fairly straight on the Right Hand Side. If any of these three factors do not apply, then they should be corrected immediately. Minor coning or telescoping problems can be overcome quite easily. Have the operator move along the Right Hand Side of the machine near the front corner. As the carpet continues to come across and roll-up, the operator can adjust the carpet by hand in the cradle much like he would if he were rolling it up on the floor. This procedure eliminates any serious coning and as long as the carpet rolls up relatively straight on the Right Hand Side, your cut will be straight and square.



PRIOR TO CUTTING

➤ Prior to making your cut, there may be a slight buckle of carpet on the table. To eliminate this, turn the Right Hand Side Rollers into FWD and the Left Hand Side Rollers in REV, and then tap the Jog Button.

➤ Ensure that the measured length of the carpet on the Top Row of the Counter equals the preset length programmed into the Bottom Row of the counter.

NOTE: If you wish to give a couple of extra inches to the programmed cut, you can do so by pressing the Jog Button. If you try to step on the Foot Cable, the machine's rollers will not work because they are locked out after the pre-set length is reached. To re-activate the Foot Cable,

press the  (F2/RST) button on the counter.

CUTTING THE CARPET

- Turn Both Rollers Switches to the "OFF" positions - **VERY IMPORTANT!**
- Clear the area of any potential hazards (i.e. someone may be leaning on the machine or have their hand in the path of the Cutting Bar).
- Push and hold the Cutting Bar's Toggle Switch to FWD.
- Once the Cutter has completed the cut, release the Toggle Switch.
- Because it is a Two-Way Cutter, you do not have to return the Cutting Bar back to the home end of the machine for the next cut.



NOTES:

- Use **extreme caution and common sense** when activating the cutting bar. Should you need to stop the cutting bar's progress at any time during a cut, just release the toggle switch immediately.
- Over time the Cutter may start to make a vibrating (humming) sound when it is running. If so lightly lubricate the Cutting Bar Cable with a water-based lubricant such as WD-40. Spray the Cable at the top of the middle pulley just under the cutting track. Run the Cutter back and forth a few times to work the lubricant in and then wipe off any excess. **Do not over lubricate!**

WRAPPING THE ROLLS


- To wrap your cut piece, turn the Right Hand Side Rollers to FWD and the Left Hand Side Rollers to OFF. Secure your stretch film or plastic under the edge of the carpet, step on the Foot Cable along the Right Hand Side of the machine, and wrap the roll accordingly. The same can be done to the balance roll on the Left Hand Side by turning the Left Hand Side Rollers in REV and the Right Hand Side Rollers to OFF.



REMOVING/DUMPING ROLLS FROM THE MACHINE

➤ Once cutting and wrapping is complete, you can now remove the cut piece from the machine's Right Hand Side Cradle without the need of a lift truck. Switch both the Left Hand Side and the Right Hand Side Rollers to OFF. While holding the Right Hand Side Cradle Handle with your right hand, pull up on the Black-handled Cradle Release Latch (located to the right of the machine's control panel) with your left hand and gently lower the Right Hand Side cradle to its DOWN position. Push the roll off of the machine and return the Right Hand Side Cradle to its **Normal** locked position.

NOTE: Heavier rolls and cuts should be removed with a lift truck, and not by way of the Dumping Mechanism, for safety and to avoid damage to your machine..



IMPORTANT NOTES:

➤ Although the Load Cradle (Left Side) is designed to handle rolls up to 28 inches in diameter, the Roll Up Cradle (Right Side) in its Normal position is designed to accept rolls only up to 24 inches in diameter. However, for larger rolls, you can shift the Right Hand Side Cradle to its Expanded Cradle position and engage the "Support Pin" at the far end of the machine (see Page 13 for details). In this expanded position, the Right Hand Side Cradle can now handle larger rolls (up to 28 inches in diameter). **ATTEMPTING TO ROLL UP ROLLS LARGER THAN THIS CAN CAUSE SERIOUS DAMAGE TO THE MACHINE AND IS NOT RECOMMENDED!**

➤ The roll capacities noted above along with the machine's overall performance will vary depending on the roll's weight, how tightly it is rolled, and whether or not it is slightly compressed or oblong around its circumference.

REVERSE ROLLING PROCEDURES

NOTE: When REVERSE ROLLING the carpet, follow the instructions listed in the **MAIN OPERATING PROCEDURES** section for **LOADING THE ROLL OF CARPET**, **PREPARING TO MEASURE** and **PROGRAMMING THE COUNTER**. Follow the instructions below for **STARTING THE ROLL UP PROCESS**, **ROLLING UP THE CARPET** and **MEASURING THE TAIL END OF THE CARPET** because they are done differently than previously listed. Then refer back to **ROLLING THE CARPET STRAIGHT**, **CUTTING THE CARPET** and **REMOVING THE ROLLS FROM THE MACHINE** as previously illustrated in the **MAIN OPERATING PROCEDURES** section of this manual.

- When Reverse Rolling or Back Rolling carpet, a cardboard core (no wider than 4 inches in diameter) **must** be used.
- With both Rollers in FWD, advance the carpet onto the Right Hand Side Cradle bringing the edge of the carpet to rest at about the middle of the cradle.
- Place your core into the cradle and flip the carpet up so it rests on top of and covers the left half of the core.
- Engage the Right Hand Side Cradle by raising it up and folding the cradle over the carpet so it pinches the carpet up against the core.




ROLLING UP THE CARPET

- With the carpet pinched in place, switch the Right Hand Side Rollers to REV and keep the Left Hand Side Rollers in FWD.
- Tap the Jog Button until the carpet starts to wrap itself around the core and completes about 3/4 of its first turn.
- At this time, lift up on the Reverse Roll Pressure Plates Handle located to the right of the main control panel. This will engage the series of stainless steel plates that run the length of the machine near the middle of the Right Hand Side Cradle.



- While gently holding this Handle in place, press the Jog Button to continue the advancement of the carpet. You will only have to hold the Handle in place for 1 or 2 seconds at which time you will see the plates actually force the carpet around the core. Once you see the carpet is starting to wrap around the core, release the Handle to its original position.

- Continue to press the Jog Button or Foot Cable and hold the Right Hand Side Cradle in the folded up position until you get 3 to 5 turns on the core, then return the Right Hand Side Cradle to it's original position.





NOTES:

- If you are working with a stiffer backed carpet you may get better results by tapping the Jog Button instead of pressing and holding it down.
- Remember the difference between using the Jog Button and the Foot Cable with respect to the Pre-set programmed length - using the Jog Button will override this feature.
- Again, if the carpet buckles slightly during the initial start-up, you can eliminate this buckling by momentarily stopping the Left Hand Side Rollers and then quickly turning them back to FWD.
- **Reverse rolling takes a little more practice and patience, take your time and don't give up.**

MEASURING THE "TAIL END" OF THE CARPET

- You must remember that when measuring a full or partial roll, you have to take into account the last section or "tail end" of carpet that doesn't get measured by the Counter after the material passes over the Counting Wheel. Using a tape, measure the section of material between the back edge of the carpet and the Cutting Track, and add it to the amount that is already recorded on the Counter's Screen. Use the Conversion Table if necessary.






VINYL PROCEDURES

- Although Vinyl flooring can be handled in the same fashion as previously detailed in the carpet procedures, some of these exceptions or options may apply:
- Instead of loading the roll on the Left Hand Side with the edge coming up from the **Bottom**, you can also load the material with the edge coming over the **Top** with the "**Pattern**" facing up. In order to advance the vinyl across to the Right Hand Side, you will have to switch the Left Hand Side Rollers into REV and provide a little more manual assistance to help the material get started. This is a little tougher procedure and takes practice, but will obviously enable you to detect any flaws or damage to the vinyl's surface during operation.
- To avoid damaging your resilient vinyl flooring, we do not recommend using the "Dumping" mechanism on the machine's Right Hand Side. Dropping the roll to the floor from the machine's cradle can cause damage to the flooring, even if it is wrapped correctly. The use of a lift truck or manually by one or two employees is recommended for removing the roll from the machine.

"EXTRA SUPPORT PIN" ON ROLL-UP SIDE CRADLE

- Please note that your machine is equipped with an engageable "Support Pin" located at the back end of the machine's Roll-Up Side Cradle (Right Side). When engaged, this "pin" will provide additional support to the Roll-Up Side Cradle and help to minimize roll coning/telescoping, especially when handling larger rolls of material.



NOTES:

- If you wish to utilize this "pin", it must be engaged immediately after you get the carpet started on the Roll-Up Side Cradle (approx. 3-5 turns). You will not be able to engage the "pin" once a larger/heavier piece has begun to be rolled up! In addition, once the "pin" is engaged, you will no longer be able to fold up the Roll-Up Cradle or use the Roll Dump Mechanism on this cradle.
- Therefore, depending on your situation and specific needs at the time, you will need to anticipate prior to performing any roll-ups whether or not you wish to engage the "pin".

IMPORTANT SAFETY AND MAINTENANCE TIPS

- **USE EXTREME CAUTION AND CARE WHEN OPERATING THE MACHINE AT ALL TIMES. KEEP THE OPERATING AREA CLEAR OF ALL UNAUTHORIZED PERSONNEL AND POTENTIAL HAZARDS. YOUR "E-Z CUT" IS A MACHINE NOT A TOY, NEVER ALLOW CHILDREN NEAR IT!**
- **WHEN PERFORMING ANY MAINTENANCE WORK ON THE MACHINE, ALWAYS DISCONNECT THE MACHINE FROM ITS POWER SOURCE.**
- **ALWAYS MAKE SURE THE MACHINE IS LEVEL DURING OPERATION. AN UNLEVEL MACHINE MAY CAUSE CONING AND WALKING OF THE MATERIAL, AND DAMAGE TO THE MACHINE MAY OCCUR.**
- **WHEN THE MACHINE IS NOT IN USE, SWITCH BOTH ROLLERS TO "OFF". DISCONNECT THE MACHINE FROM ITS POWER SOURCE WHEN LEFT OVERNIGHT.**
- **IN THE EVENT OF AN ELECTRICAL STORM, THE MACHINE SHOULD BE UNPLUGGED TO PREVENT POTENTIAL DAMAGE TO THE ON-BOARD ELECTRONIC EQUIPMENT.**
- **WHEN THE MACHINE IS NOT IN USE, ALWAYS KEEP THE "COUNTER WEIGHT ARM" (LOCATED DIRECTLY ABOVE THE COUNTING WHEEL) IN THE "UP" POSITION.**
- **THINK BEFORE YOU ACT AND USE COMMON SENSE! SHOULD YOU BE UNSURE WITH ANY OF THE MACHINE'S OPERATING FEATURES, CALL OUR OFFICE DIRECTLY AT TOLL FREE 1-800-661-5156.**

ROUTINE MAINTENANCE SCHEDULE

DAILY:

- Check for any oil leakage from the gearboxes. If there is a leakage, discontinue the use of the machine and call E-Z CUT immediately
- Use an air pressure hose or a high-powered vacuum to clean out floor covering residue, fibres, and dust build-up from the cutting track and surface of machine.
- Ensure that the 2 O-rings on the Counting Wheel are in good condition and that the Top Pressure Wheel is putting good downward pressure on the Counting Wheel. See pages 19 and 21.

BI-WEEKLY:

- Clean Under Front and Back Cutting Track Cover Plates - remove the cover plates and clean out floor covering residue, fibres, and dust build-up.
- Check that the screws that secure the Bladeholder to its base are always snug.

SCHEDULE "A" MAINTENANCE: (Perform Schedule "A" Maintenance after the first 3 and 6 months of operation and then every 6 months thereafter):

- Use the 1/8-inch and 5/32-inch Set Screw Wrenches (found in the back of this manual) to check that all visible Set Screws are tight. Pay particular attention to each Roller Bearing and each Gearbox Shaft.
- Check all Bearing Holder Bolts and Nuts.
- De-grease Cradle Locking Positions on Roll-Up side.
- Grease all 4 Caster Wheels.
- Check to see if the Cutter makes a vibrating (humming) sound when it is running. If so, lightly lubricate the Cutting Bar Cable with a water-based lubricant such as WD-40. Spray the Cable at the top of the middle pulley just under the cutting track. Run the Cutter back and forth a few times to work the lubricant in and then wipe off any excess. **Do not over lubricate!**

SCHEDULE "B" MAINTENANCE: (Perform Schedule "B" Maintenance yearly):

- Change the oil in the Gearbox (refer to page 17 of this Manual).
- Check the Cutter's Cable tension by first positioning the Cutting Bar at the far end of the machine and removing the top cover panel at the front of the machine. Press down on the portion of Cable that is just past the front pulley. There should be about 1/2" to 1" of 'play' in the Cable. If there is more 'play' in the Cable or it appears very loose, contact an E-Z CUT representative immediately.

NOTES:

- **In order to maintain your machine's optimum performance and to ensure any potential machine problems are covered under the "E-Z CUT WARRANTY", the above procedures must be followed and adhered to at all times.**
- **The Roller Bearings are factory greased and do not require regular greasing.**


RECORD OF MAINTENANCE

Record Date of Delivery:			
Length Of Time Since Delivery:	Maintenance Required:	Maintenance Performed By:	Date:
3 Months	Schedule A		
6 Months	Schedule A		
1 Year	Schedule A And B		
1 Year 6 Months	Schedule A		
2 Years	Schedule A And B		
2 Years 6 Months	Schedule A		
3 Years	Schedule A And B		
3 Years 6 Months	Schedule A		
4 Years	Schedule A And B		
4 Years 6 Months	Schedule A		
5 Years	Schedule A And B		
5 Years 6 Months	Schedule A		
6 Years	Schedule A And B		
6 Years 6 Months	Schedule A		
7 Years	Schedule A And B		
7 Years 6 Months	Schedule A		
8 Years	Schedule A And B		

IMPORTANT NOTES:

- Always perform the daily and bi-weekly maintenance in addition to following this long-term maintenance schedule
- Continue to perform scheduled maintenance for the life of the machine.

GEARBOX OIL REPLACEMENT



Use 9 to 11 ounces of oil per gearbox for your EC-1. Due to the mounting configuration, the window on the gearbox cannot be used to monitor the amount of oil however you must ensure that the gearbox is never more or less than half filled with oil at all times! Quaker State Synthetic Gear Oil is recommended but any brand between 75W to 90W Synthetic Gear Oil or Synthetic High Pressure Gear Oil is acceptable.

1. Disconnect the electrical power supply to your machine.
2. Remove the gearbox cover. Cover the motor with a rag so oil does not seep into it. Remove the bottom front Allen bolt to drain oil. Ensure that the Allen bolt is put back in place when done draining.
3. Remove the red breather plug on top of the gearbox and fill with 9 to 11 ounces of oil. Ensure that the gearbox is about half filled with oil and reinstall the top breather plug and the gearbox cover.
4. Repeat steps 1, 2 and 3 to change the oil in the gearbox on the opposite side of the machine.
5. Ensure all plugs are in place, remove the rag from both motors and reinstall both gearbox covers before reconnecting power and operating the machine again.

TROUBLESHOOTING THE COUNTER

➤ If you are unable to find the Main Screen on your counter refer to the table below. Simply follow the steps beside the picture of the screen that you are currently on to return to the Main Screen.

If in the "PRO.CODE" screen, press the



(ENT) button followed by the



(<ESC)

button twice.



If in the "PROGRAM MODE" screen, press the



(<ESC)



(SEL>)

button to scroll back to the Main Screen.



If in the "SCALE FACTORS" screen, press the



(<ESC)



(SEL>)

button to scroll back to the Main Screen.



NOTE: If you are on any other Screen simply press the



(<ESC) button until you return to the Main Screen.

TROUBLE SHOOTING MEASURING ACCURACY PROBLEMS

- Refer to the Operators Manual to ensure the correct operating procedures are being followed.
- Ensure all operators are using the machine in the same manner and fashion.
- Ensure that the 2 black rubber O-rings on the Wood Counting Wheel are both present and in good condition.
- Before running the carpet across the Cutting Track, make sure the Top Pressure Wheel is in the down position and putting good downward pressure on the Counting Wheel. If it is not pressing down on the Counting Wheel follow the instructions on page 21.
- Always measure the material with the Backing Side Down and Pile Side Up.
- Make sure to always line up the material with the Cutting Track and reset the Counter to “0.00” (zero) before attempting to measure.
- If you are measuring a full or balance roll, remember to add the “Tail End” of the carpet to what the Counter Screen is showing because this “Tail End” amount will not be measured by the Counter once it passes over the Counting Wheel.

IMPORTANT NOTE:

Please note that your Counter has only one setting and will react slightly different to various material backings (i.e. jute, actionback, rubber, foam (kanga), enhancer, unitary, etc.) and/or thickness. To determine the slight variances among these different backings and/or thickness, it is best to run a small piece (approx. 35') through the machine 3 to 5 times. Record your findings and the variance, (if any) so it can be factored in as a reference when you measure that type of backing (i.e. you may need to add 1" (2.5cm) for every 20' of kanga.

MEASURING ACCURACY TESTS

If the machine is still not measuring accurately after going through the Trouble Shooting list follow these instructions in order to Benchmark the Accuracy of your Machine:

1. **Make a Photocopy of tests located on the next page.**
2. Perform the described tests and **record** your results.
3. If the tests indicate a possible problem with the calibration **Fax** the results along with your name, phone number, company name and location to **(204) 237-9339**.
4. After reviewing the results an E-Z Cut representative will get in touch with you to assist you in resolving the problem.

Date:	Phone#:
Company Name and Location:	Your Name:

ENCODER TEST

1. Make a mark or line on both the Counting Wheel and the Table, and line them up.
2. **Reset the Counter to “0.00”.**
3. Turn the Counting Wheel by hand one complete rotation so that the marks on the Counting Wheel and the Table line up. Record the length indicated on the Counter Screen in the box below (i.e. 2.00).
4. **Reset the Counter to “0”** and repeat step #3 about 15 to 20 times. In each case be sure to **record** the Counter Reading in the box below and then **Reset the Counter to “0”**.

1.	2.	3.	4.
5.	6.	7.	8.
9.	10.	11.	12.
13.	14.	15.	16.
17.	18.	19.	20.

NOTE: If the same reading comes up each time, your encoder is operating properly.

MEASURING ACCURACY TEST

1. Select a roll of material (35’ or longer) that you use most often and unroll it on the floor.
2. Using a Tape Measure, start at one end (make sure the end you start from is square) and make a mark on the backing at exactly 5’ increments all the way to 30’.
3. Roll up the material and load onto the machine.
4. Position the starting end of the carpet exactly on the Cutting Track and **Reset the Counter**.
5. Advance the material and stop with the 5’ mark exactly on the cutting track. **Record the Counter reading** in the Table below. Continue for every 5’ increment up to and including 30’ (make sure the material is rolling up straight).

Record Material Type And Weight:	
5’ _____ , _____”	20’ _____ , _____”
10’ _____ , _____”	25’ _____ , _____”
15’ _____ , _____”	30’ _____ , _____”

1. Re-roll the roll to its starting position with the starting end exactly on the cutting track and **Reset the Counter**
2. This time, advance the material but do not stop until the 30’ mark is exactly on the Cutting Track. **Record the Counter reading** in the Table below.
3. Repeat this five or six times to determine consistency.

1. 30’ _____ , _____”	4. 30’ _____ , _____”
2. 30’ _____ , _____”	5. 30’ _____ , _____”
3. 30’ _____ , _____”	6. 30” _____ , _____”

FAX RESULTS TO 204-237-9339


ADJUSTING THE TOP COUNTER PRESSURE WHEEL

- Disconnect the Machine from the power supply.
- Remove Front Access Panel, and the Allen bolts from the Top Control Panel in order to slide it to the side. This should give you access to the Counter Weight Bracket.

- Note:**
- If you need more room at this point you can remove the Counter by carefully unplugging the 3 Wiring Clips (1 Small, 1 Medium and 1 Large) from the bottom of the Counter (see page 26 for photo). **Do not remove the wires from the Wiring Clips.**
 - Use a small Phillips Screwdriver to loosen the two screws (see page 26 for photo) on either side of the Counter and unhook the Plastic Clips Plates.
 - Use a Small Flathead Screwdriver to gently pry up the top of the Counter and carefully lift it out of the console.
- Use a 7/16" Wrench to loosen the Bolt on the top left side of the Counter Weight Bracket.
 - Push the grey Top Pressure Wheel into the down position.
 - Insert a large Flathead screwdriver between the right side of the Counter Weight Bracket and the edge of the Wiring Box. This procedure will allow the shock to apply the necessary pressure to the Counting Wheel without hitting the side of the Wiring Box..
 - Re-tighten the top Bolt and remove the screwdriver.
 - If necessary re-install the Counter, plug in the Wiring Clips, and re-attach the plastic Clip Plates and Phillips screws.
 - Re-install the Front Access Panel and the Top Control Panel.



- This photo of a Machine (with the Counter and Switches removed) shows the Counter Weight Bracket (#1) lined up with the Shock (#2) at a 45 degree angle. This is what the assembly should look like with the Counter Weight Wheel in the **UP** position.





- This photo shows the position the Counter Weight Bracket (#1) should be in with the Counter Weight Wheel in the **DOWN** position. To make your adjustment loosen the Bolt (#2) and put your Counter Weight Wheel Down so the Bracket is in this vertical position.

BLADEHOLDER INSTRUCTIONS

- Remove the two Wing Nuts that secure the Cutter Wheels and slide them off the Shaft.
- Use the 5/32 Allen Wrench (found at the back of the Operator's Manual) to remove the two black screws that hold the curved Blade Lock in place.
- Remove the Blade Lock and slide the Blades off the locating pin.
- With the Blades removed, clean out any carpet debris or fibers from inside the Bladeholder.
- Re-position the Blades or dispose of them and replace with new ones.
- Reinstall the Blade Lock and Cutter Wheels.

NOTES:

- Due to the configuration of the Bladeholder, you should be able to use all four corners of each Blade before replacing them.
- The Wing Nuts and Setscrews on the Bladeholder should be checked at least once a day to ensure that they are tight. Activation of the Bladeholder coupled with numerous cuts can cause the Setscrews to loosen over time. This would result in your Bladeholder not performing as intended.




EC-1 PARTS LIST

Control Panel



KEY	PART NUMBER	QTY	DESCRIPTION
1	BH-4WHEEL	1	Bladeholder
2	LGPBF100	1	Red Screen Electronic Counter
3	9040-00054-A	1	Jog Button, Siemens
4	IC111932	1	Cutter Switch, Advance, Spring
5	IC111927	1	Left Roller Switch, Advance, Locking
6	IC111927	1	Right Roller Switch, Advance, Locking

Front Of Machine




KEY	PART NUMBER	QTY	DESCRIPTION
1	L413ACB-TLB	4	Castor Wheels
2	CBL-1085	34'	Foot Cable
3	See Belt List	17	Black Laced Belts
4	See Belt List	25	Tan Glued On belts
5	ROLLER-#1	1	Outside Roller On Left Side
6	ROLLER-#2	1	Inside Roller On Left Side, Connected To Motor
7	ROLLER-#3	1	Inside Roller On Right Side
8	ROLLER-#4	1	Outside Roller On Right Side, Connected To Motor
9	ROLLER-#5	1	Small Rollup Roller On Right Side
10	See Belt List	3	Tan Laced Belts


Belt List – Measure Belt On Machine To Confirm Length And Width

PART NUMBER	QTY	SIZE AND DESCRIPTION OF BELTS
CPUL12X65.75	4	Left Side Black Laced Belt, 12" Wide And 65.75" Long
CPUL4X65.75	1	Left Side Black Laced Belt, 4" Wide And 65.75" Long
CPUL4X51.25	3	Right Side Black Laced Belt, 4" Wide And 51.25" Long
CPUL2X51.25	2	Right Side Black Laced Belt, 2" Wide And 51.25" Long
CPUL4X36	5	Right Side Black Laced Belt, 4" Wide And 36" Long
CPUL2X36	2	Right Side Black Laced Belt, 2" Wide And 36" Long
RTL4X51.25	3	Right Side Tan Laced Belt, 4" Wide And 51.25" Long
RT6X19.125	3	Left Side Tan Glued On Belt, 6" Wide And 19.125" Long
RT1X17.5	22	Right Side Tan Glued On Belt, 1" Wide And 17.5" Long

Right Side And Top Of Machine




KEY	PART NUMBER	QTY	DESCRIPTION
1	VFDL3507M	1	Left Side Motor, Baldor, 3/4hp, 110v, Single Phase
2	B-6	1	Reverse Roll Pressure Plates Screw On Knob
3	4010-00004-A	1	Counter Wheel
4	N/A	1	Counter Weight Wheel
5	DK-75	1	Right Hand Side Cradle Release T-Handle
6	EOVM50-50	1	Right Side Gearbox, 50:1




Counter Wheel Viewed From Under Machine

KEY	PART NUMBER	QTY	DESCRIPTION
1	2121-0500	1	Encoder
2	ORING	2	O-Rings

Left Side And Wiring Of Machine



KEY	PART NUMBER	QTY	DESCRIPTION
1	N/C	2	Fuses, Check Amperage On Each Fuse
2	VFDL3507M	1	Left Side Motor, Baldor, 3/4hp, 110v, Single Phase
3	EOVM50-60	1	Left Side Gearbox, 60:1
4	752622	1	150N Gas Spring Shock For Counter Weight Arm
5	Check # On Block	1	Contact Block For Switch, Siemens, See Below
6	N/C	3	Wiring Clips For Counter, See Below
7	Check # On Relay	1	Roller Contactor/Relay



Close Up Of Switch And Counter Wiring

KEY	PART NUMBER	QTY	DESCRIPTION
1	Check # On Block	Varies	Contact Block For Switch, Siemens
2	N/C	2	Screw That Holds Down Counter, 1 On Each Side
3	N/C	3	Wiring Clips For Counter, 1 Small, 1 Medium, 1 Large (in back)

