




Carpet and tape goes under all 3 rollers





Roll Cutting Machines

Unpacking and setup
Roll up side cradle support
pin
Controlling the roll on the
load side cradle shuttle
Measuring, Cutting, and
Packaging
Reverse Rolling / Remnants
Correct measuring the

Base Cutting Machines

balance of a roll or remnant

Unpacking and setup
Blade Information (EZ Slitter)
Blade Information (EZ Slitter

Jr.)
Tape Dispenser
Adjustments and Cutting

Contact EZCUT

420 Des Meurons St. Unit 106 Winnipeg, Manitoba Canada, R2H 2N9

Phone: 1.204.235.1122
Toll Free: 1.800.661.5156
Fax: 1.204.237.9339

Email: talktous@ezcut.com

